



PRO ARMOR

**HONDA 400EX
FOOT PEG
INSTALLATION INSTRUCTIONS**

ITEM	DESCRIPTION	QUANTITY
1	FOOT PEG ®MAXI-MIZER	2
2	HEX CAP SCREW M8 x 1.25P x 60MM LG.	2
3	NYLOCK NUT M8	2
4	TUBE SPACER	2
5	HEX CAP SCREW M8 x 1.25P x 25MM LG	2
6	FLAT WASHER M8	6

- 1) REMOVE EXISTING OEM HEEL GUARD AND FASTENERS.
- 2) LOCATE NEW FOOT PEG ®MAXI-MIZER TO ALIGN WITH OEM FOOT PEG HOLE
- 3) MARK LOCATION OF INNER MOUNTING HOLE ON FOOTPEG AND DRILL NEW .354 DIA HOLES THROUGH THE FOOTPEG, MATCHING THE HOLE SPACING IN THE MAXI-MISER.
- 4) LOOSELY INSTALL NEW FOOT PEG ®MAXI-MIZER USING SUPPLIED ITEMS #2, #3, #4, #5 AND #6.
- 5) REINSTALL OEM HEEL GUARD USING OEM MOUNTING LOCATIONS AND ITEM #5 (THE OEM HEEL GUARD PLASTIC MAY NEED TO BE TRIMMED OR GENTLY PULLED OUT OF THE WAY IN SOME INSTANCES)

1. Torque M8 Bolts to 22 ft. lbs

2. Maintenance: Periodically, check all fasteners for tightness and re-torque to above spec.

3. Customer Service: For further information contact Pro Armor (951) 270-0559