



**PRO ARMOR**

**INSTALLATION INSTRUCTIONS  
HONDA TRX250EX Frame Skid Plate**

To avoid injury to yourself or damage to the vehicle, read these instructions completely before installation.

**1. Parts List:**

Item	Part Name	Description	Qty
1	Frame Skid Plate	Skid Plate	1
2	Frame Skid Spacer	1/8"	1
3	Bolt, Hex Flange Head	M6 x 1.0P x 65mm Long Gr.10.9	1
4	Bolt, Hex Flange Head	M6 x 1.0P x 16mm Long Gr.10.9	2
5	Bolt, Hex Flange Head	M6 x 1.0P x 25mm Long Gr.10.9	2
6	Back Plates	1/4" Square	2
7	Nylock Nut	M6	3
8	Hook	.240 PA Hook	2

**2. Preparation:**

- a) Set rear parking brake, turn gas petcock to OFF and stand bike up on the rear grab bar. Make sure vehicle is secure while installing your Skid Plate.
- b) Remove OEM bolts mounting the OEM Frame Cover to the Frame. You may discard the OEM mounting bolts and plastic frame cover.

**3. Installation:**

- a) **Top Mount:** Pressing the skid plate against the bike, loosely install (1) Item #3 bolt through the top dimpled hole and thread into the 1/8" spacer, frame opening, and M6 Nylock Nut.
- b) **Two Middle Mounts:** Install (2) Item #4 Bolts through the two dimpled holes and thread into (2) Item #8 hooks placed over the frame tube. Loosely tighten hooks in place.
- c) **Two Bottom Mounts:** Install (2) Item #5 Bolts into the slotted holes and frame. Secure from opposite side of frame using (2) Item #6 spacers and (2) Item #7 Nuts. Loosely tighten bolts to hold skid plate in position.
- d) After Skid Plate hooks are oriented correctly, tighten all supplied bolts to 12 ft-lbs.

**4. Maintenance:** Periodically check all fasteners for tightness and re-torque.

**5. Care and Cleaning:** Clean using a soft cloth and/or scotch brite type pad.

**6. Customer service:** For further information call Pro Armor at 951-270-0559