



PRO ARMOR

INSTALLATION INSTRUCTIONS

A-Arm Guards Honda TRX400EX

To avoid injury to yourself or damage to the ATV, please read and understand these instructions completely before proceeding with installation.

1. Parts List:

Item	Part Name	Description	Qty
1	A-Arm Guard	Left	1
2	A-Arm Guard	Right	1
3	A010022 .570 PA Hook	Large Hooks	2
4	A010023 .360 PA Hook	Small Hooks	4
5	Bolt, Hex Flange Head	M6 x 1.0P x 20mm Long Gr.10.9	6

2. Preparation:

a) Set/Lock rear parking brake on bike, turn gas petcock to 'Off' position and stand bike upright so that it is sitting on the rear grab bar. Make sure vehicle is secure and will not fall over while installing your new A-Arm Guards.

3. Installation:

a) Insert (2) Item #5 Bolts through the two holes farthest from the wheel on the underside of the A-Arm Guard Slotted Holes. From the opposite side, secure the A-Arm by mounting (2) Item #4 Small Hooks over the frame tubing and fasten with the M6 bolts.

b) Insert (1) Item #5 Bolt through the one hole closest to the wheel on the underside of the A-Arm Guard Slotted Holes. From the opposite side, secure the A-Arm by mounting (1) Item #3 large hook over the frame tubing and fasten with the M6 bolt.

c) The logo should face towards the front of the bike. Position the hooks so that the A-Arm Guards lies flush with the A-Arm Tubes. Make sure that the rear edge of the A-Arm is up against the A-Arm tube before tightening the bolts.

d) Turn handlebar back-n-forth to check for clearance between the front rims and A-Arm Guard. If there is interference, re-orient hooks, re-tighten, and check again.

e) Once position of A-Arm and hooks are orientated correctly, tighten all six bolts to 6 ft-lbs.

4. Maintenance: Periodically check all fasteners for tightness and re-torque as required.

5. Customer service: For further information call Pro Armor at 951-270-0559