



# PRO ARMOR

## INSTALLATION INSTRUCTIONS HONDA TRX450R Frame Skid Plate

To avoid injury to yourself or damage to the vehicle, read these instructions completely before installation.

### 1. Parts List:

Item	Part Name	Description	Qty
1	Frame Skid Plate	Skid Plate	1
2	A010023 PA .360 Hook	Small Hook	3
3	A010022 PA .570 Hook	Large Hook	2
4	Bolt, Hex Flange Head	M6 x 1.0P x 20mm Long Gr.10.9	6
5	Rubber Strip	1"x4"	4
6	A010033 PA .479 Hook	L Hook	1

### 2. Preparation:

a) Lock rear parking brake on quad, turn gas petcock to Off and stand quad upright on the rear grab bar. Make sure vehicle is secure and will not fall over while installing your new skid plate.

b) Remove OEM bolts mounting the OEM Frame Cover to the Frame using a 10mm socket wrench. You may discard the OEM mounting bolts and plastic frame cover.

### 3. Installation:

a) Top Mount: Pressing the skid plate against the bike, hooking the leading edge of the skid over the frame. Loosely install (1) Item #4 bolt through the one top dimpled slotted hole from the bottom up and thread into (1) Item #2 hook placed over the frame tube from the opposite side. Loosely attach bolt to hold skid plate in position.

b) Apply Item #5 strips to skid plate in areas where frame will rest against skid plate. This will keep the plate from rattling and help keep it in place once all hooks are tightened down.

c) Upper Middle Mount: Install (1) Item #4 bolt through (1) Item #6 hook. Hook will compress onto center of frame.

c) Middle Mounts: Install (2) Item #4 bolts through the two middle dimpled slotted holes from the bottom up and thread into (2) Item #3 hooks placed over the frame tube from the opposite side. Loosely attach bolts to hold skid plate in position.

d) Bottom Mounts: Install (2) Item #4 bolts through the two bottom dimpled slotted holes from the bottom up and thread into (2) Item #2 hooks placed over the frame tube from the opposite side. Loosely tighten bolts to hold skid plate in position.

e) After skid plate hooks are oriented correctly, tighten all 6 supplied bolts to 12 ft-lbs.

4. Customer service: For further information call Pro Armor at 951-270-0559

Top Mount: (1) Item #4, (1) Item #2

Upper Middle Mount: (1) Item #4, (1) Item #6

Middle Mounts: (2) Item #4, (2) Item #3

Bottom Mounts: (2) Item #4, (2) Item #2

