



PRO ARMOR

INSTALLATION INSTRUCTIONS

A-Arm Guards

KAWASAKI KFX700

K032020

To avoid injury to yourself or damage to the ATV, please read and understand these instructions completely before proceeding with installation.

1. Parts List:

Item	Part Name	Description	Qty
1	A-Arm Guard	Left	1
2	A-Arm Guard	Right	1
3	A010022 PA Hook	Hook .570	6
4	Bolt, Hex Flange Head	M6 x 1.0P x 16mm Long Gr.10.9	6

2. Preparation:

- Set/Lock rear parking brake on bike, turn gas petcock to 'Off' position and stand bike upright so that it is sitting on the rear grab bar. Make sure vehicle is secure and will not fall over while installing your new A-Arm Guards.

3. Installation:

- Install the Left and Right A-Arms using (6) #3 Hooks and (6) #4 flange bolts supplied into the 6 dimpled slotted holes. Only engage a few threads of the bolt into each hook.
- The logo should face towards the front of the bike. Position the hooks so that the A-Arm Guards lies flush with the A-Arm Tubes. Then turn the hooks so that the hooks are on top of the tube. Make sure that the rear edge of the A-Arm is up against the A-Arm tube before tightening the bolts.
- Turn handlebar back-n-forth to check for clearance between the front rims and A-Arm Guard. If there is interference, re-orient hooks, re-tighten, and check again.
- Once position and hook orientation are correct, tighten all six supplied bolts to 6 ft-lbs.

4. Maintenance: Periodically check all fasteners for tightness and re-torque as required.

5. Care and Cleaning: Restore original finish using scuff pads rubbing in same direction of grain lines.

6. Customer service: For further information call Pro Armor at 951-270-0559