



**PRO ARMOR**

# KAWASAKI

## KFX700

### FOOT PEG MAXI-MISER INSTALLATION INSTRUCTIONS

ITEM	DESCRIPTION	QUANTITY
1	FOOT PEG ®MAXI-MIZER	2
2	HEX FLANGE SCREW M8 x 1.25P x 60MM LG.	4
3	NYLOCK NUT M8	4
4	TUBE SPACERS	4

- 1) REMOVE AND DISCARD (2) BOLTS AND (2) NUTS ON THE HEEL GUARD MOUNTS.
- 2) OPEN EXISTING OEM FOOT PEG HOLES TO .354 DIA.
- 3) LOCATE NEW FOOT PEG ®MAXI-MIZER TO ALIGN WITH OEM FOOT PEG HOLES
- 4) LOOSELY INSTALL NEW FOOT PEG ®MAXI-MIZER USING 1 SET OF SUPPLIED BOLTS, SPACERS AND NUTS .
- 5) MARK DESIRED LOCATION FOR SECOND MOUNTING HOLE ON OEM FOOT PEG USING MAXI-MISER AS A TEMPLATE.
- 6) DRILL NEW .354 DIA HOLE IN OEM FOOT PEG
- 7) INSTALL REMAINING SET OF SUPPLIED BOLTS, SPACERS,AND NUTS.

**1. Torque M8 Bolts to 22 ft. lbs**

**2.Maintenance:** Periodically, check all fasteners for tightness and re-torque to above spec.

**Customer service:** For further information call Pro Armor at 951-270-0559