



**PRO ARMOR**

**POLARIS  
FRAME SKID**

**INSTALLATION INSTRUCTIONS**

USE (3) OEM ¼-20 BOLTS  
WITHOUT WASHERS  
TORQUE @ 10 FT LBS.

USE SUPPLIED HARDWARE:  
(1) HOOK (.360)  
(1) M6 HEX HEAD BOLT  
TORQUE @ 5 FT LBS. / (60 IN. LBS)



USE SUPPLIED HARDWARE:

- (2) ¼-20 X ¾" LONG HEX HEAD BOLTS
- (2) 1/8" THICK SPACERS
- (2) NYLON WASHERS

INSERT BOLT INTO BOTTOM OF SKID PLATE AND INSTALL SPACER AND NYLON RETAINING WASHER FROM OPPOSITE SIDE. (LOCATES BETWEEN SKID PLATE & FRAME)

SLIP (1) NYLON WASHER OVER THREAD AND AGAINST SPACER TO HOLD IN PLACE WHILE INSTALLING THE SKID PLATE.

TORQUE @ 10 FT LBS.

- 1. Maintenance:** Periodically, check all fasteners for tightness and re-torque to above spec.
- 2. Care and Cleaning:** Use Scotch Brite Pads (rub in one direction), to restore original line grain finish as required.
- 3. Customer service:** For further information call Pro Armor at 951-270-0559

P032022