



**PRO ARMOR**

# INSTALLATION INSTRUCTIONS

## SUZUKI Z400

### SWING ARM GUARD (TROUGH)

Please read these instructions completely before installation to avoid injury to yourself or damage to the bike or accessory.

#### 1. Parts List:

Item	Part Name	Description	1
1	Swing Arm Guard		1
2	Link Guard		1
3	90° Flat Head Screw For Link Guard	M6 x 1.0P, 20mm Lg Gr. 10.9	2
4	Bolt, Hex Head	M8 x 1.25P x 40mm Lg Gr. 10.9	2
5	Bolt, Hex Head	M8 x 1.25P x 20mm Lg Gr. 10.9	2
6	Flat Washer	M8	4
7	Spacer	.125"	2

#### 2. Preparation:

- Set/Lock rear parking brake on bike, turn gas petcock to Off position and stand bike upright so that it is sitting on the rear grab bar. Ensure Bike is stable to prevent falling over during installation.
- Remove existing OEM parts if applicable.

#### 3. Installation for Swing Arm Guard:

- Install the Swing Arm Guard using (4) supplied bolts and washers. Item 4, 5, & 6.
- Install the Link Guard using (2) supplied screws (Item 3) and (2) Spacers (Item 7).

**4. Maintenance:** Periodically check all fasteners for tightness and re-torque as required.

**5. Care and Cleaning:** Use Scotch Brite Pads (rub in one direction), to restore original line grain finish as required.

**6. Customer Service:** For further information call Pro Armor at 951-270-0559