



PRO ARMOR

INSTALLATION INSTRUCTIONS SUZUKI LTA700

FORWARD SKID PLATE

Item	Description	Quantity
1	Forward Skid Plate	1
2	M6 X 16mm Long Hex Head Bolt	6
3	Adhesive backed rubber strips (Long Forward Skid Plate)	2

FORWARD SKID PLATE:

NOTE: To reduce front skid plate vibration, cut rubber strips, (Item #4) into 2" lengths and equally space them between frame and towards the outer edges of the front skid plate.

- 1) Insert top of forward skid plate "under" rear edge of OEM front shroud while inserting tab of front shroud into slot of skid plate.
- 2) Insert (6) item #3 bolts through slotted holes located on forward skid plate and loosely attach to ATV frame.
- 3) Customer service: For further information call Pro Armor at 951-270-0559

NOTE: When forward skid plate is positioned correctly, torque bolts to 4.5 ft-lb (6 N.M.)